

## Clean Earth Sampling Protocol Georgia

METHODS (1)	PARAMETERS	TPH - GRO (GA Sites)	TPH - DRO (GA Sites)	TRPH (Florida Sites)	PAH's	TOTAL METALS - Arsenic, Cadmium, Chromium and Lead	TOTAL METALS - Arsenic, Cadmium, Chromium, Lead, Mercury, Selenium and Silver	BTX	PCB's
		8015	8015	FLPRO	8270	6010	6010 / 7471	8260B	6010 / 7471
	FREQUENCY								
Gasoline or Aviation Fuel	1 Sample per every 280 tons 1 Sample metals per project	X (1)		X (1)		X (2)		X (2)	
Virgin Petroleum Product Other Than Gasoline or Aviation Fuel	1 Sample per every 280 tons 1 Sample metals per project	X (1)	X (1)	X (1)	X	X (2)		X (2)	
Petroleum from vehicle accidents	1 Sample per every 280 tons 1 Sample metals per project	X (1)	X (1)	X (1)	X	X (2)		X (2)	
Used Oil (UST or AST)	1 Sample per every 280 tons 1 Sample metals per project	X (1)	X (1)	X (1)	X		X (2)	X (2)	X

0

(2) TCLP may be required based on the total levels of Benzene and/or metals.

(3) All sampling must be done in accordance with SW846.

NOTE - Based on current and historical site usage, additional analysis may be requested.